



















# Gear boxes Series RS and RT

**RT**

## Mounting positions

<b>RT</b> <b>TA</b> <b>RT/RT</b> Output	 <p><b>B3 (std)</b></p>	 <p><b>B6</b></p>	 <p><b>B7</b></p>	 <p><b>B8</b></p>
	 <p><b>V5</b></p>	 <p><b>V6</b></p>	 <p><b>F (std)</b></p>	 <p><b>Fi</b></p>

<b>TA</b> Input	 <p><b>10 (std)</b></p>	 <p><b>11</b></p>	 <p><b>12</b></p>	 <p><b>13</b></p>
--------------------	--	--	---	--

<b>RT/RT</b> Input	 <p><b>20 (std)</b></p>	 <p><b>21</b></p>	 <p><b>22</b></p>	 <p><b>23</b></p>
	 <p><b>24</b></p>	 <p><b>25</b></p>	 <p><b>26</b></p>	 <p><b>27</b></p>